

GEAR CHART

Created by Wrench 2 Win - www.wrench2win.com

Sprocket	10	11	12	13	14
65	6.500	5.909	5.417	5.000	4.643
66	6.600	6.000	5.500	5.077	4.714
67	6.700	6.091	5.583	5.154	4.786
68	6.800	6.182	5.667	5.231	4.857
69	6.900	6.273	5.750	5.308	4.929
70	7.000	6.364	5.833	5.385	5.000
71	7.100	6.455	5.917	5.462	5.071
72	7.200	6.545	6.000	5.538	5.143
73	7.300	6.636	6.083	5.615	5.214
74	7.400	6.727	6.167	5.692	5.286
75	7.500	6.818	6.250	5.769	5.357
76	7.600	6.909	6.333	5.846	5.429
77	7.700	7.000	6.417	5.923	5.500
78	7.800	7.091	6.500	6.000	5.571
79	7.900	7.182	6.583	6.077	5.643
80	8.000	7.273	6.667	6.154	5.714
81	8.100	7.364	6.750	6.231	5.786
82	8.200	7.455	6.833	6.308	5.857
83	8.300	7.545	6.917	6.385	5.929
84	8.400	7.636	7.000	6.462	6.000
85	8.500	7.727	7.083	6.538	6.071
86	8.600	7.818	7.167	6.615	6.143

Smaller Front Driver Is Better For Acceleration. +3 to 5 teeth in the wet.